

Step 1. Attach extrusions to base with smooth side facing out. Use 1 **long** knob per extrusion.



Step 2. Attach top to extrusions using 1 **long** knob per leg.



Step 3. Insert 2 front panels.

