

Step 1. Attach extrusions to base using 2 **long** knobs per extrusion.



Step 3. Insert infill panels.



Step 2. Attach extrusions to top using 2 **long** knobs per extrusion.

