

**Step 1.** Attach extrusions to base using two **long** knobs.



**Step 4.** Place Optional shelves onto gussets.



**Step 2.** Attach v-legs to counter top using two **long** knobs.



**Step 3.** Install infill panel. Attach counter assembly to base using two **long** knobs; attach to rear extrusions to top using two **long** knobs.

