

Step 1. Insert **short** knob, attach t-nut- do not tighten completely.



Step 2. Attach shelf to column; tighten **short** knob.

