



1. Make sure that you have the right angle and height before you lock the bracket using provided tool.



2. Attach the X tv bracket to your monitor. Make sure you are not fixing it up side down, check female.



3. Slide the bracket in the female section supplied.



4. Push all the way down, make sure the bracket locks in position.